



R2C EXTREME SERIES HONDA PIONEER 1000 REPLACEMENT AIR
FILTER KIT
INSTALLATION INSTRUCTIONS

PART# OR10557



- REMOVE EXISTING STOCK AIR FILTER
- PLACE THE R2C AIR FILTER IN THE AIR CLEANER HOUSING AS SHOWN IN ABOVE PHOTO. MAKE SURE THE FILTERS FLANGE SEALING BEAD IS SEATED IN SEALING CHANNEL.
- NEXT INSTALL THE BREATHER CLAMP AS SHOWN IN THE PHOTO MARKED WITH THE SOLID YELLOW ARROW.
- TIGHTEN CLAMP SCREW FIRMLY MAKRED WITH THE YELLOW OUTLINED ARROW

R2C PERFORMANCE PRODUCTS
605 TOWER RD • MUNDELEIN, IL 60060
(224) 778-5454
R2CPERFORMANCE.COM